














Messungen an Adaptern



-	BNC / F / F / BNC Adapter Billi;
---	----------------------------------

		- 2.....6GHz
		- 1dB / DIV
		- SMA ST / ST / Bu / Bu Adapter
		- 2.....6GHz
		- 0,2dB / DIV
		- SMA St / St / Bu / Bu Adapter B
		- 2.....6GHz
		- 0,2dB / DIV
		- SMA / N / N / SMA Adapter Mit
		- 2.....6GHz
		- 0,2dB / DIV
		- N / APC-7 / APC-7 / N Adapter
		- 2.....6GHz
		- 0,2dB / DIV
		- APC-7 / N / N / APC-7 Adapter
		- 2.....6GHz
		- 0,2dB / DIV

Die obere Linie auf dem
Bildschirm ist die Referenz